

Eicher DCM

Sl.no	spare parts	Qty	Parts	Charge
1	EicherDCM Spare parts,Air filter	no	3005	120
2	Eicher DCM Spare parts,Break shoe	set	3300	1400
3	Eicher DCM Spare parts,Break pad	set	3200	1200
4	Eicher DCM Spare parts,hub bearing f inner	no	2880	600
5	Eicher DCM Spare parts,hub bearing f outer	no	2880	600
6	Eicher DCM Spare parts,hub oil seal	no	490	220
7	Eicher DCM Spare parts,tube oil seal	no	490	480
8	Eicher DCM Spare parts,break dic	no	2010	320
9	Eicher DCM Spare parts,hub check nut	no	790	120
10	Eicher DCM Spare parts,check nut lock	no	650	80
11	Eicher DCM Spare parts,hub spender	no	350	2220
12	Eicher DCM Spare parts,Shocker absorber front	no	4990	480
13	Eicher DCM Spare parts,shocker absorber rear	no	2590	480
14	Eicher DCM Spare parts,shocker absorber bush	no	2300	80
15	Eicher DCM Spare parts,stablizer bar bush front	no	200	980
16	Eicher DCM Spare parts,stablizer bar bush rear	no	200	980
17	Eicher DCM Spare parts, link bush front	no	200	480
18	Eicher DCM Spare parts,link bush rear	no	200	480
19	Eicher DCM Spare parts,spring main leaf	no	200	1200
20	Eicher DCM Spare parts,2nd	no	1990	980
21	Eicher DCM Spare parts,3rd	no	1990	600
22	Eicher DCM Spare parts,4th	no	1880	480
23	Eicher DCM Spare parts,5th	no	1700	380
24	Eicher DCM Spare parts,spring main leaf front	no	1990	900
25	Eicher DCM Spare parts,2nd	no	1990	860
26	Eicher DCM Spare parts,3th	no	1790	640
27	Eicher DCM Spare parts,4th	no	1600	480
28	Eicher DCM Spare parts,5th	no	1500	380
29	Eicher DCM Spare parts,spring bush small	no	700	280
30	Eicher DCM Spare parts,spring bush big	no	780	340
31	Eicher DCM Spare parts,spring claim	no	500	180
32	Eicher DCM Spare parts,spring bush metal	no	790	400
33	Eicher DCM Spare parts,center bolt	no	250	180
34	Eicher DCM Spare parts,fuel filter	no	590	360
35	Eicher DCM Spare parts,oil filter	no	580	360
36	Eicher DCM Spare parts,oil(castol)	ltr	480	360
37	Eicher DCM Spare parts,oil mak	ltr	450	300
38	Eicher DCM Spare parts,oil rimula	ltr	450	300
39	Eicher DCM Spare parts,gear oil castrol	ltr	480	280
40	Eicher DCM Spare parts,gear oil mak	ltr	450	280
41	Eicher DCM Spare parts,trasmission oil	ltr	450	120

42	Eicher DCM Spare parts,hyudraulic oil	ltr	480	480
43	Eicher DCM Spare parts,axle bearing	no	2990	980
44	Eicher DCM Spare parts,axle oil seal inner	no	690	480
45	Eicher DCM Spare parts,axle oil seal outer	no	690	480
46	Eicher DCM Spare parts,axle tube oil seal	no	500	680
47	Eicher DCM Spare parts,rear differential assy	no	7000	2700
48	Eicher DCM Spare parts,differential side bearing	no	2880	1800
49	Eicher DCM Spare parts,tail inner bearing	no	1980	1200
50	Eicher DCM Spare parts,tail outer bearing	no	1900	1280
51	Eicher DCM Spare parts,tail oil seal	no	700	300
52	Eicher DCM Spare parts,crown & tail assy	set	50000	3400
53	Eicher DCM Spare parts,ball joint upper	no	900	700
54	Eicher DCM Spare parts,ball joint lower	no	900	700
55	Eicher DCM Spare parts,arm lower	no	1970	400
56	Eicher DCM Spare parts,arm upper	no	1970	400
57	Eicher DCM Spare parts,arm bush lower	no	900	380
58	Eicher DCM Spare parts,arm bush upper	no	900	380
59	Eicher DCM Spare parts,break hose front	no	2100	700
60	Eicher DCM Spare parts,break hose rear	no	1990	700
61	Eicher DCM Spare parts,back light	no	1550	900
62	Eicher DCM Spare parts,back light bulb	no	50	40
63	Eicher DCM Spare parts,side light	no	150	400
64	Eicher DCM Spare parts,side light bulb	no	50	40
65	Eicher DCM Spare parts, head light	no	6900	1300
66	Eicher DCM Spare parts,head light bulb	no	250	580
67	Eicher DCM Spare parts,head gasket	no	2550	3000
68	Eicher DCM Spare parts,head gasket set	set	3100	2700
69	Eicher DCM Spare parts,water pump	no	4000	1700
70	Eicher DCM Spare parts,fan belt	no	1380	320
71	Eicher DCM Spare parts,power steering belt	no	850	120
72	Eicher DCM Spare parts,acc belt	no	700	120
73	Eicher DCM Spare parts,steering damper	no	6700	780
74	Eicher DCM Spare parts,steering relay	no	6400	980
75	Eicher DCM Spare parts,steering drop arm	no	650	1200
76	Eicher DCM Spare parts,steering bucket kit	no	1250	1800
77	Eicher DCM Spare parts,break bucket kit	no	380	700
78	Eicher DCM Spare parts,wheel cylinder assy	no	2200	680
79	Eicher DCM Spare parts,feed pump	no	4600	380
80	Eicher DCM Spare parts,fuel supply pump	no	4700	980
81	Eicher DCM Spare parts,fuel totter & head	set	2200	800
82	Eicher DCM Spare parts,delivery valve	set	850	40
83	Eicher DCM Spare parts,oil supply pump	set	3700	4200
84	Eicher DCM Spare parts, valve oil seal	set	610	1180
85	Eicher DCM Spare parts,clutch plate	set	5000	2700
86	Eicher DCM Spare parts,pressure plate	no	5200	2180
87	Eicher DCM Spare parts,release bearing	no	2670	1200
88	Eicher DCM Spare parts, master cylinder kit	no	1690	980

89	Eicher DCM Spare parts, master cylinder	no	3200	1380
90	Eicher DCM Spare parts, clutch cylinder upper	no	2550	880
91	Eicher DCM Spare parts, clutch cylinder lower	no	2150	580
92	Eicher DCM Spare parts, brake booster	no	16590	2680
93	Eicher DCM Spare parts, cross bearing	no	2200	450
94	Eicher DCM Spare parts, link	no	790	450
95	Eicher DCM Spare parts, c.v joint	no	18800	700
96	Eicher DCM Spare parts, drive shaftassy	no	18800	980
97	Eicher DCM Spare parts, rear spring shackel	no	1450	650
98	Eicher DCM Spare parts, tie rod end small	no	990	480
99	Eicher DCM Spare parts, tie rod end big	no	1100	480
100	Eicher DCM Spare parts, tie rod end	set	990	780
101	Eicher DCM Spare parts, king pin bearing	set	990	1700
102	Eicher DCM Spare parts, king pin kit	set	1980	800
103	Eicher DCM Spare parts, raditor cap	set	650	40
104	Eicher DCM Spare parts, wheel nut & bolt	no	650	800
105	Eicher DCM Spare parts, self armature	no	3880	1300
106	Eicher DCM Spare parts, self carbon	no	1880	980
107	Eicher DCM Spare parts, self carbon rocker	no	1280	640
108	Eicher DCM Spare parts, self plunger	no	1350	480
109	Eicher DCM Spare parts, timing belt	no	1650	2700
110	Eicher DCM Spare parts, glow plug	no	1280	700
111	Eicher DCM Spare parts, engine mounting	no	1680	880
112	Eicher DCM Spare parts, gear box mounting	no	1580	980
113	Eicher DCM Spare parts, wipper blade	no	490	80
114	Eicher DCM Spare parts, battery	no	15000	120
115	Eicher DCM Spare parts, break oil	ltr	450	30
116	Eicher DCM Spare parts, power steering oil	ltr	450	40
117	Eicher DCM Spare parts, key lock set	set	480	1600
118	Eicher DCM Spare parts, parking cable rear	no	2580	480
119	Eicher DCM Spare parts, parking cable front	no	2880	480
120	Eicher DCM Spare parts, accelator cable	no	1680	300
121	Eicher DCM Spare parts, km cable	no	880	780
122	Eicher DCM Spare parts, rear axle con	no	1250	680
123	Eicher DCM Spare parts, spring pad	no	780	800
124	Eicher DCM Spare parts, piston	set	680	2700
125	Eicher DCM Spare parts, piston ring	set	1680	2180
126	Eicher DCM Spare parts, linner	set	1110	3230
127	Eicher DCM Spare parts, intake valve	set	3580	800
128	Eicher DCM Spare parts, exhust valve	set	650	800
129	Eicher DCM Spare parts, vale guide	set	650	1400
130	Eicher DCM Spare parts, vaive seat	set	600	980
131	Eicher DCM Spare parts, connecting bearing	set	600	3700
132	Eicher DCM Spare parts, main bearing	set	2180	3880
133	Eicher DCM Spare parts, cam shaft bearing	set	2800	2600
134	Eicher DCM Spare parts, thrust washer	set	690	700
135	Eicher DCM Spare parts, crank shaft	no	18500	4200

136	Eicher DCM Spare parts,connecting rod	no	850	880
137	Eicher DCM Spare parts, valve set	set	1230	580
138	Eicher DCM Spare parts,grease	kg	380	480
139	Eicher DCM Spare parts,dhoti	nos	30	
140	Eicher DCM Spare parts,sk oil	ltr	60	
141	Eicher DCM Spare parts,water paper	no	30	
142	Eicher DCM Spare parts,4w yok and teeth	set	6800	1700
143	Eicher DCM Spare parts,2w yok and teeth	set	5800	1700
144	Eicher DCM Spare parts,main bearing oil seal	no	1880	3600
145	Eicher DCM Spare parts,u-bolt	no	680	450
146	Eicher DCM Spare parts,mobile filter	no	680	320
147	Eicher DCM Spare parts,diesel filter	no	480	320
148	Eicher DCM Spare parts,cv joint assembly	no	1880	400
149	Eicher DCM Spare parts,dust guard	set	1120	900
150	Eicher DCM Spare parts,engine oil	ltr	480	450
151	Eicher DCM Spare parts,coolant	ltr	280	220
152	Eicher DCM Spare parts,distilled water	ltr	50	80
153	Eicher DCM Spare parts,bonnet cable	set	650	600
154	Eicher DCM Spare parts,hand break cable	set	2850	1400
155	Eicher DCM Spare parts,door rubber	set	690	900
156	Eicher DCM Spare parts,safe guard	set	6500	2200
157	Eicher DCM Spare parts,fog light	set	1120	900
158	Eicher DCM Spare parts,horn	no	3250	450
159	Eicher DCM Spare parts,pop.shaft-yoke & teeth	no	6800	1280
160	Eicher DCM Spare parts,fuse	no	25	10
161	Eicher DCM Spare parts,wheel bearing	no	2500	800

