

Maruti van

Sl No	Spare parts	qnty	Price	charge
1	Maruti Van Spare parts, Air Filter	No	550	150
2	Maruti Van Spare parts, Brake Shoe	Set	1280	500
3	Maruti Van Spare parts, Brake Pad	Set	1000	400
4	Maruti Van Spare parts, Hub Bearing F Inner	No	1380	480
5	Maruti Van Spare parts, Hub Bearing F Outer	No	1380	480
6	Maruti Van Spare parts, Hub Oil Seal	No	280	220
7	Maruti Van Spare parts, Tube Oil Seal	No	280	480
8	Maruti Van Spare parts, Brake Disc	No	1580	700
9	Maruti Van Spare parts, Hub Check Nut	No	180	60
10	Maruti Van Spare parts, Check Nut Lock	No	120	60
11	Maruti Van Spare parts, Hub Splender	No	600	500
12	Maruti Van Spare parts, Shock Absorber Front	No	4900	780
13	Maruti Van Spare parts, Shock Absorber Rear	No	880	250
14	Maruti Van Spare parts, Shock Absorber Bush	No	80	60
15	Maruti Van Spare parts, Stablizer Bar Bush Front	No	120	380
16	Maruti Van Spare parts, Stablizer Bar Bush Rear	No	180	280
17	Maruti Van Spare parts, Link Bush Front	No	150	220
18	Maruti Van Spare parts, Link Bush Rear	No	180	220
19	Maruti Van Spare parts, Spring Main Rear	No	1450	450
20	Maruti Van Spare parts, 2ND	No	900	300
21	Maruti Van Spare parts, 3RD	No	800	250
22	Maruti Van Spare parts, 4TH	No	700	180
23	Maruti Van Spare parts, 5TH	No	750	120
24	Maruti Van Spare parts, Spring Main Front	No	1000	480
25	2Maruti Van Spare parts, 2ND	No	900	320
26	Maruti Van Spare parts, 3RD	No	800	220
27	Maruti Van Spare parts, 4TH	No	850	280
28	Maruti Van Spare parts, 5TH	No	700	180
29	Maruti Van Spare parts, Spring Bush Small	No	380	380
30	Maruti Van Spare parts, Spring Bush Big	No	180	380
31	Maruti Van Spare parts, Spring Clamp	No	120	90
32	Maruti Van Spare parts, Spring Bush Metal	No	380	300
33	Maruti Van Spare parts, Center Bolt	No	70	220
34	Maruti Van Spare parts, Fuel Filter	No	680	380
35	Maruti Van Spare parts, Oil Filter	No	150	180
36	Maruti Van Spare parts, Oil (Castrol)	Ltr	490	150
37	Maruti Van Spare parts, Oil Mak	Ltr	460	150
38	Maruti Van Spare parts, Oil Rimula	Ltr	450	150
39	Maruti Van Spare parts, Gear Oil Castrol	Ltr	480	360
40	Maruti Van Spare parts, Gear Oil Mak	Ltr	470	360
41	Maruti Van Spare parts, Trasmission Oil	Ltr	470	220

42	Maruti Van Spare parts, Hyudraulic Oil	Ltr	490	180
43	Maruti Van Spare parts, Axle Bearing	No	490	480
44	Maruti Van Spare parts, Axle Oil Seal Inner	No	120	220
45	Maruti Van Spare parts, Axle Oil Seal Outer	No	120	220
46	Maruti Van Spare parts, Axle Tube Oil Seal	No	120	2300
47	Maruti Van Spare parts,Rear Differential Assy	No	14000	2700
48	Maruti Van Spare parts, Differential Side Bearing	No	800	600
49	Maruti Van Spare parts, Tail Inner Bearing	No	680	480
50	Maruti Van Spare parts, Tail Outer Bearing	No	780	480
51	Maruti Van Spare parts, Tail Oil Seal	No	120	380
52	Maruti Van Spare parts, Crown & Tail Assy	Set	12500	3200
53	Maruti Van Spare parts,Ball Joint Upper	No	1100	350
54	Maruti Van Spare parts, Ball Joint Lower	No	1100	350
55	Maruti Van Spare parts, Arm Lower	No	700	250
56	Maruti Van Spare parts, Arm Upper	No	700	250
57	Maruti Van Spare parts, Arm Bush Lower	No	380	180
58	Maruti Van Spare parts, Arm Bush Upper	No	380	180
59	Maruti Van Spare parts, Brake Hose Front	No	480	380
60	Maruti Van Spare parts, Brake Hose Rear	No	190	280
61	Maruti Van Spare parts, Back Light	No	480	80
62	Maruti Van Spare parts, Back Light Bulb	No	20	20
63	Maruti Van Spare parts, Side Light	No	220	80
64	Maruti Van Spare parts, Side Light Bulb	No	20	20
65	Maruti Van Spare parts, Head Light	No	2900	150
66	Maruti Van Spare parts, Head Light Bulb	No	190	50
67	Maruti Van Spare parts, Head Gasket	No	180	1600
68	Maruti Van Spare parts, Head Gasket Set	Set	580	1200
69	Maruti Van Spare parts, Water Pump	No	880	750
70	Maruti Van Spare parts, Fan Belt	No	180	120
71	Maruti Van Spare parts, Power Steering Belt	No	900	120
72	Maruti Van Spare parts, Acc Belt	No	900	80
73	Maruti Van Spare parts, Steering Damper	No	480	380
74	Maruti Van Spare parts, Steering Relay	No	650	480
75	Maruti Van Spare parts, Steering Drop Arm	No	890	580
76	Maruti Van Spare parts, Steering Relay Kit	No	680	620
77	Maruti Van Spare parts, Brake Bucket Kit	No	80	320
78	Maruti Van Spare parts, Wheel Cylinder Assy	No	590	280
79	Maruti Van Spare parts, Feed Pump	No	500	220
80	Maruti Van Spare parts, Fuel Supply Pump	No	500	480
81	Maruti Van Spare parts, Fuel Totter & Head	Set	2600	980
82	Maruti Van Spare parts, Delivery Valve	Set	3600	20
83	Maruti Van Spare parts, Oil Supply Pump	Set	1280	120
84	Maruti Van Spare parts, Valve Oil Seal	Set	480	180
85	Maruti Van Spare parts, Clutch Plate	Set	990	800
86	Maruti Van Spare parts, Pressure Plate	No	1100	770
87	Maruti Van Spare parts, Release Bearing	No	800	480
88	Maruti Van Spare parts, Master Cylinder Kit	No	880	450

89	Maruti Van Spare parts, Master Cylinder	No	1480	600
90	Maruti Van Spare parts, Clutch Cylinder Upper	No	480	380
91	Maruti Van Spare parts, Clutch Cylinder Lower	No	1100	320
92	Maruti Van Spare parts, Brake Booster	No	4600	1300
93	Maruti Van Spare parts, Cross Bearing	No	890	280
94	Maruti Van Spare parts, Link	No	650	60
95	Maruti Van Spare parts, C V Joint	No	3500	400
96	Maruti Van Spare parts, Drive Shaft Assy	No	4000	480
97	Maruti Van Spare parts,Rear Spring Shackel	No	450	120
98	Maruti Van Spare parts, Tie Rod End Small	No	590	230
99	Maruti Van Spare parts, Tie Rod End Big	No	590	280
100	Maruti Van Spare parts, Tie Rod End	Set	590	330
101	Maruti Van Spare parts, King Pin Bearing	Set	500	480
102	Maruti Van Spare parts, King Pin Kit	Set	300	480
103	Maruti Van Spare parts, Radiator Cap	Set	480	20
104	Maruti Van Spare parts, Wheel Nuts & Bolts	No	180	220
105	Maruti Van Spare parts, Self Armature	No	1880	350
106	Maruti Van Spare parts, Self Carbon	No	480	280
107	Maruti Van Spare parts, Self Carnon Rocker	No	420	280
108	Maruti Van Spare parts, Self Plunger	No	480	120
109	Maruti Van Spare parts, Timing Belt	No	990	600
110	Maruti Van Spare parts, Glow Plug	No	600	80
111	Maruti Van Spare parts, Engine Mounting	No	550	380
112	Maruti Van Spare parts, Gear Box Mounting	No	580	280
113	Maruti Van Spare parts, Wiper Blade	No	270	30
114	Maruti Van Spare parts, Battery	No	5000	20
115	Maruti Van Spare parts, Brake Oil	Ltr	480	20
116	Maruti Van Spare parts, Power Steering Oil	Ltr	490	40
117	Maruti Van Spare parts, Key Lock Set	Set	1980	700
118	Maruti Van Spare parts, Parking Cable Rear	No	390	480
119	Maruti Van Spare parts, Parking Cable Front	No	390	480
120	Maruti Van Spare parts, Accelator Cablel	No	180	150
121	Maruti Van Spare parts, Km Cable	No	480	400
122	Maruti Van Spare parts, Rear Axle Corn	No	190	300
123	Maruti Van Spare parts, Spring Pad	No	230	380
124	Maruti Van Spare parts, Piston	Set	4500	1700
125	Maruti Van Spare parts, Piston Ring	Set	1550	1600
126	Maruti Van Spare parts, Linner	Set	4600	980
127	Maruti Van Spare parts, Intake Valve	Set	3200	680
128	Maruti Van Spare parts, Exhuast Valve	Set	2600	680
129	Maruti Van Spare parts, Vale Guide	Set	1500	480
130	Maruti Van Spare parts, Vaive Seat	Set	1700	700
131	Maruti Van Spare parts, Connecting Bearing	Set	900	1400
132	Maruti Van Spare parts, Main Bearing	Set	680	1400
133	Maruti Van Spare parts, Cam Shaft Bearing	Set	880	900
134	Maruti Van Spare parts, Thrush Washer	Set	350	70
135	Maruti Van Spare parts, Crank Shaft	No	9000	480

136	Maruti Van Spare parts, Connecting Rod	No	780	250
137	Maruti Van Spare parts, Valve Set	Set	1880	600
138	Maruti Van Spare parts, Grease	Kg	480	20
139	Maruti Van Spare parts, Dhoti	Kg	30	
140	Maruti Van Spare parts, Sk Oil	Ltr	30	
141	Maruti Van Spare parts, Water Paper	No	30	
142	Maruti Van Spare parts, 4W Yok And Teeth	Set	880	380
143	Maruti Van Spare parts, 2W Yok And Teeth	Set	880	380
144	Maruti Van Spare parts, Main Bearing Oil Seal	No	350	1300
145	Maruti Van Spare parts, U-Bolt	No	180	80
146	Maruti Van Spare parts, Mobil Filter	No	120	120
147	Maruti Van Spare parts, Diesel Filter	No	700	120
148	Maruti Van Spare parts, CV Joint Assembly	No	5000	300
149	Maruti Van Spare parts, Dust Guard	Set	480	600
150	Maruti Van Spare parts, Engine Oil	Ltr	490	150
151	Maruti Van Spare parts, Coolant	Ltr	290	80
152	Maruti Van Spare parts, Distilled Water	Ltr	60	10
153	Maruti Van Spare parts, Bonnet Cable	Set	90	80
154	Maruti Van Spare parts, Hand Brake Cable	Set	480	550
155	Maruti Van Spare parts, Door Rubber	Set	3600	400
156	Maruti Van Spare parts, Safe Guard	Set	2800	380
157	Maruti Van Spare parts, Fog Light	Set	1200	280
158	Maruti Van Spare parts, Horn	No	880	80
159	Maruti Van Spare parts, Pop.Shaft-Yoke & Teeth	No	880	400
160	Maruti Van Spare parts, Fuse	No	20	10
161	Maruti Van Spare parts, Wheel Bearing	No	990	350